

(2) Continuous watch on VHF CH 16, keeping AIS in operation (do not leave the bridge unattended);

(3) Continuous appropriate watch at all times (e.g., watch for dragging anchor of own vessel and other vessels);

(4) Keeping enough distance from offshore facilities, other vessels, or the shore;

(5) Use of adequate anchor cable;

(6) abandoning anchoring, changing to heaving-to, etc., depending on the situation; and

(7) Stand-by engine and full readiness by the crew (when there is a fear of weather aggravation).

Please take all possible measures to prepare for dragging-anchor, especially for car carriers, container carriers, or other vessels with high freeboard that are susceptible to the wind!

Supervised by Yokohama Coast Guard Office Issued by Tokyo Wan Association for Marine Safety

Publishing this sheet is supported J by the Japan Marine Center